

Arlington Sewing Machine Supply

817-460-4992

RIBBON KEY FOB INSTRUCTIONS

Supplies Needed

- 10" of grosgrain ribbon 7/8" wide
- 10" of cotton webbing 1 1/4" wide
- 10" of 1/2" wide Steam-A-Seam 2

Sewing Thread

Stabilizers: It-med tear-away and adhesive type

1 set of fob hardware

Embroidery lettering should be .5 inches (10-11 mm)

Embroidery Instructions

Step A: To center embroidery-lettering, place a pin 2 1/2" from left short end of ribbon. Hoop tear-away and adhesive stabilizer with adhesive on top. Score adhesive stabilizer and peel away paper to expose tacky surface. Place ribbon on stabilizer and center needle over pin to center embroidery. Stitch lettering.

Step B: Remove ribbon from stabilizer and remove the excess stabilizer. Place embroidery face down on to a towel and press the backside.

Sewing Instructions

Step 1: Iron the 1/2" Steam-A-Seam 2 on the backside of the embroidery. **Step 2:** Peel paper off ribbon and iron on to webbing.

Step 3: Sew along both long edges of ribbon (A walking foot does wonderful for this purpose with the thick webbing)

Step 4: Fold in half and stitch both ends together.

Step 5: Crimp hardware on with pliers. (Place small amount of batting over grooves of pliers and secure with painters tape, this keeps the pliers from scratching the hardware.)

Step 6: Add the ring.

What a wonderful gift.

